

MULTI-STATION SUCTION

IN A FEW EASY STEPS

SALES@VANIMAN.COM
(760) 723-1498

STATIONS

TECHNICIAN ACTIVATED (MANUAL)



SWITCHES/REMOTES

SMART REMOTE SWITCH FOR COMBINING BOX (PN 96068B)



START/STOP DUST COLLECTORTO COMBINING BOX

SMART SWITCH (PN 96068)




START/STOP DUST COLLECTORTO COMBINING BOX



PNEUMATIC VALVE (PN 10518)*
*REQUIRES ADDITIONAL PARTS AND COMPRESSED AIR

HANDPIECE OR LATHE ACTIVATED (AUTOMATIC)



5 AMP OR SMALLER

SMART AUTOPILOT (PN 96073)



START/STOP DUST COLLECTORTO COMBINING BOX




PNEUMATIC VALVE (PN 10518)*
*REQUIRES ADDITIONAL PARTS AND COMPRESSED AIR

MILL ACTIVATED (AUTOMATIC)



MILL REMOTE (PART NUMBERS VARY BY MILL MODEL)



START/STOP DUST COLLECTORTO COMBINING BOX

SMART MILL REMOTE (PN 96082)



START/STOP DUST COLLECTORTO COMBINING BOX



PNEUMATIC VALVE (PN 10518)*
*REQUIRES ADDITIONAL PARTS AND COMPRESSED AIR

COMBINING BOXES

SMARTSPEED REMOTE HUB (PN 96111)



START/STOP DUST COLLECTOR,
AUTOMATIC SPEED CONTROL

STANDARD REMOTE HUB (PN 96109)



START/STOP DUST COLLECTOR

START/STOP DUST COLLECTOR

REMOTE COMBINING BOX (PN 96069)



START/STOP DUST COLLECTOR

DUST COLLECTORS

V6 SE (PN 10281)



STONEVAC BRUSHLESS SC MODELS



STONEVAC II MODELS



HOW WE CONNECT
MULTIPLE STATIONS TO
A DUST COLLECTOR

