



---

## **PACKING LIST**

---

1 - ODOR Filter with Gasket

---

## **ABOUT THE PRODUCT**

---

This filter is designed to make your job safer and more comfortable by removing most odors, fumes and vapors from the air processed by the Pure Breeze FX Fume Extractor. This filter is designed to be used internally along with the HEPA Filter of your Pure Breeze FX Fume Extractor.

---

## **INSTALLATION INSTRUCTIONS**

---

1. Remove the top filter access panel from the Pure Breeze FX Fume Extractor by unscrewing the four black thumb nuts.
2. Remove the dirty Odor Filter from the unit, and properly discard.
3. Remove any packaging from the Odor Filter, and carefully align the frame with the walls of the Pure Breeze FX and ensure that the silver label on the Odor Filter is facing upwards.
4. Slide the filter into the unit until it stops and the front of the Odor Filter is in line with the front of the HEPA Filter.
5. Remount the top filter access panel, using the four thumb nuts to secure it to the case.
6. Replace the Odor Filter when the filter becomes excessively dirty, the odors begin to return, or at least once a year.