



MICROBLASTING ACCESSORIES

Part No.	Nozzle Size, Inches (mm)	Color	Recommended Media
Long Lasting Crystal Tips (2 per package)			
97902	Medium, .032" (.8mm)	Blue	25/50 μm Al_2O_3
97903	Large, .048" (1.2mm)	Black	50/100 μm Al_2O_3 , 50 μm Glass
97904	Extra Large, .065" (1.6mm)	Red	100-250 μm Al_2O_3 , 50/100 μm Glass
Precision Tungsten Carbide Tips (1 per package)			
97905	Small, .026" (.65mm)	Yellow	25 μm Al_2O_3
97906	Medium, .036" (.91mm)	Green	50/100 μm Al_2O_3 , 50 μm Glass
97907	Large, .059" (1.5mm)	Violet	100-250 μm Al_2O_3 , 50/100 μm Glass

Tips

Long Lasting Crystal Tips

Ultra-hard sapphire crystal inserts provide economic tip solution.

Precision Tips

Ultra precision Tungsten Carbide for highest spray control.



Media

Vaniman's new line of abrasive media is of the highest quality and purity. High quality media virtually eliminates media impurities and increases blasting precision and consistency. 15 lb package

Part No.	Material	Size	Applications
97921	Aluminum Oxide	25 μm	Fine surfacing of metal, porcelain and acrylic.
97922	Aluminum Oxide	50 μm	Removal of oxides. Preparation of porcelain faces before firing.
97923	Aluminum Oxide	100 μm	Deflasking. Alloy preparation for porcelain work.
97924	Aluminum Oxide	250 μm	Bulk removal of investment and tough oxide layers. Rough surface preparation.
97925	Glass Bead	50 μm	Smoothing/polishing. Devesting porcelain. Finishing of occlusal surfaces/crown interiors.

Note: Larger quantities available, contact Vaniman or your dealer for information.

Abrasive Blaster Window Protection System

The Protector shield is our newest accessory for the blasting systems. The window is protected utilizing "static cling". The shield is placed on the inside of any blaster window and protects the glass from scratching and fogging. When viewing clarity is reduced, the Protector is easily removed and replaced.

Protector for Vaniman SandStorm, Expert, Alpha, and all other blasters 12 pack 97950

Protector for Vaniman SandStormXL and other large cabinet blasters 12 pack 97951

"Contact Lens" Magnifier

Reduces eye strain and improves overall viewing area

"Contact Lens" Magnifier for Vaniman SandStorm, Expert, Alpha, and all other small blasters 97940

Contact Lens for Vaniman SandStormXL and other large cabinet blasters 97941

